

How to clear the "Re-wax Belt" or "Service Deck" message on StarTrac treadmill?

To clear this message from Pro, 4500, and 4000 series follow this procedure:

- (1) Enter the maintenance mode by pressing and holding the "0", "2", and "start" key at the same time, then release the "start" key.
- (2) Once in maintenance mode, use the incline down key to scroll to the parameter "LST DCK".
For 4500, 4000 models, press the "heart" key once.
- (3) The display will read "updating" then press the "stop" key.

Pro Treads use the same steps as the 4500, use the "Alpine" key in place of the "heart" key.

The 3900 and 3500 procedures are as follows:

- (1) Press the "TIME", "DISTANCE", "SPEED" keys all together for a few seconds. If the Re-wax Led does not turn off, follow the next steps.
- (2) Remove the display from the unit, on the circuit board, there are dip switches.
- (3) Locate dip switch #7 and flip it once in the opposite position. This will reset the Rewax Led.